




Puertas & Portones Automáticos, S.A. de C.V.
¡Nuestra pasión es la Solución!....

» MANUAL DE INSTALACION DE PUERTA RAPIDA SPEED-MASTER MOD.SM2600L/SM4600L.



MANUAL DE INSTALACION

*Instructions For Installation, Operating and Maintenance
Speed-Master 2600L/4600L*



(229) 288-1552

portonesautomaticos@adsver.com.mx
portonesautomaticos@prodigy.net.mx



RESIDENCIAL



COMERCIAL



INDUSTRIAL



MEMBER

IDA
International Door Association



(229) 927-5107, 167-8080, 167-8007, 151-7529.

www.adsver.com.mx

V12.18



Shear risk

Impact risk

Trap risk

Grease

Correct positioning or action

Non-permissible positioning or action

Remove and dispose of structural component or packaging

See illustrated section

See separate Installation Instructions for the control unit or additional electrical control elements

B Used Abbreviations

OFF	Top edge of finished floor line
W	Width
H	Height

1 To the Owner

This manual describes installation, operation, care and maintenance procedures for the Speed-Master® High Speed Roll-Up door. Please keep this manual in a suitable place for reference.

1.1 Receiving and Handling

Check to see that the number of packages matches with that shown on the Bill of Lading when receiving shipment of Speed-Master® High Speed Roll-Up door. Any damage to the crate or packaging material should be noted on the shipping receipt. Exterior damage may indicate interior damage. Uncrate and check the unit for shipping damage, missing parts and, if necessary, prepare freight claims against the freight carrier for any damage discovered.

1.2 Introduction

The Operating Instructions provide important information representing prerequisites for working safely with and on the industrial door.

Please carefully work your way through the Operating Instructions before putting the industrial door into operation. Thoroughly acquaint yourself not only with the „Safety“ chapter but also with the posted information signs and their meanings. You must know the arrangements and functions of all the control elements before you start up the installation for the first time.

When carrying out any work, always pay attention to the information in the Operating and Maintenance Instructions.

Furthermore, the existing regulations on accident prevention and environmental protection as well as the recognized specialist technical rules for safe and competent working must be observed.

Competent operation and careful maintenance have a considerable bearing on the performance and availability of your industrial door. Operating errors and inadequate maintenance lead to avoidable operational malfunctions. Satisfactory, permanent operational reliability and safety is only guaranteed provided the door system is expertly operated and carefully maintained.

The „**Operation**“ chapter includes all the information required for operating the door correctly. It is assumed that the operator already has special knowledge about the industrial door and its possible uses. Our installers provide instruction after the door system has been put into operation.

In the „**Maintenance**“ chapter, all the maintenance work and checks are listed and described to such an extent that any mechanic familiar with maintaining machines can perform the work competently. The maintenance instructions do not represent instructions to allow more largescale repairs to be carried out. Contact your Hörmann Flexon dealer for these kinds of repairs.

The manufacturer is not liable for any damage caused as a result of non-compliance with the Operating Instructions and the information contained therein or due to non-customary use.

2 Safety

2.1 Intended Use

Industrial doors are used to close openings for through-traffic, to safely close rooms, to make machines safe and secure, to save energy costs, to improve the room air conditions and to accelerate the flow of materials. Any other or further use is regarded as non-intended use.

The manufacturer/supplier is not liable for any damage resulting from this. The risk is borne solely by the user. The intended use also includes paying attention to the Operating Instructions and observing inspection and maintenance conditions.

2.2 Organizational Measures

Complying with Laws and Regulations

In addition to the Operating Instructions, generally applicable statutory regulations and other binding regulations for accident prevention and environmental protection must be complied with and corresponding instructions must be given in respect of these. This also applies to national regulations which must be observed locally.

Keeping the Operating Instructions Ready at Hand

Always have the Operating Instructions available at the location where the industrial door is used.

No Conversion Work

Without the supplier's approval, do not carry out any modification, attachment or conversion work on the industrial door which might compromise safety!

No Program Modifications

Do not make any program modifications (software) on programmable control systems!

Fire Extinguishers

The location and operation of fire extinguishers must be indicated by appropriate information signs! Pay attention to the statutory fire-alarm and fire-fighting regulations.

2.3 Selection and Qualification of Personnel

Instructed Personnel

Appoint only qualified and trained personnel. Responsibilities regarding operation, maintenance and repair must be clearly stipulated to ensure maximum safety!



ATTENTION

Electrical Work only by a Specialist

Work on the electrical components may only be carried out by electrical specialists and only in the de-energized state (main switch at OFF and main cable disconnected) in accordance with the electrical regulations.

2.4 Safety-Related Remarks for Specific Operating Phases



ATTENTION

Operational Shutdown during Work on the Industrial Door

All the work on the industrial door (such as maintenance and cleaning work as well as inspections) may only be performed during an operational shutdown.

Normal Operation



ATTENTION

Avoiding Danger

When operating the door care should be taken so not to cause injury or damage to personnel and vehicles.

Only Work When Protective Safety Devices are Present

Take measures to ensure that the industrial door is only operated when it is safe and in proper working order!

Only operate the industrial door when all the protective devices and safety-related devices (e.g. detachable protective devices) and emergency-OFF devices are present and functioning!

Safety devices must not be modified, dismantled or put out of operation.

Maintenance Work and Eliminating Malfunctions

Complying With Inspection Intervals

The adjustment, maintenance and inspection work and intervals stipulated in the Operating Instructions (including information about the replacement of parts/partial equipment) must be complied with! These activities may only be carried out by qualified personnel.

Original Spare Parts

Spare parts must fulfill the technical requirements stipulated by the manufacturer. This is always guaranteed when original spare parts are used.

2.5 Remarks About Possible Types of Hazard

Gas, Dust, Steam and Smoke Excluding the Risk of Fire and Explosion

Only carry out welding, burning and grinding work on the industrial door provided this work has been expressly approved. There may be a risk of fire and explosion!

Cleaning and Ventilating Beforehand

Prior to welding, burning and grinding, remove dust and combustible materials from the industrial door and its surroundings and ensure that there is adequate ventilation to avoid risk of explosion!

3 Installing

3.1 Before Starting Installation

- Take precautionary measures to make the site safe
- Check the on-site installation conditions and check measurements
- Check the quality of the mounting structure for its strength
- Choose suitable fasteners
- Unpack the door and check for damage

REPORT DAMAGE IMMEDIATELY

- Dispose of the packaging material
- Check that the delivery is complete
 - 2 side frames
 - 1 shaft with PVC curtain
 - 1 box containing hardware and operator
 - 1 bottom rail
 - Operator and shaft hood (optional)

3.2 Door Opening Preparations

The doorway opening should be square and plumb in order to achieve the best possible installation. Also, the area around the door opening must be free of pipes, electrical conduit, or other obstructions.

There should be enough wall strength to prevent unwanted movement of the door's framework during the opening and closing cycles. In some cases, it may be necessary to structurally reinforce the doorway in order to support the weight of the door. The installer must make this determination. If there are any questions concerning reinforcement of the doorway, the installer should contact the factory.

A solid flush, concrete wall which is free of obstacles, will allow the best and easiest installation.

The floor between the door jambs should also be level. If not, this condition must be compensated for when positioning the guide tracks.

Check the size of the Speed-Master® against the size of the door opening before beginning the actual installation.

IMPORTANT: The size (width x height) is written on a tag attached to one of the guide tracks. There is also a tag on the gearbox which shows the size.

If necessary, the door may be installed in an opening that is slightly narrower or wider than the door's finished size. However, the tolerance should be no more than 1 inch.

If the opening is 1 inch smaller, the guide tracks may be positioned 1/2 inch out from the jamb to compensate. Positioning the guide tracks back on the jamb at a distance more than 1/2 inch may prevent the breakaway feature on the door from operating effectively in case of accidental impact.

If the doorway is wider by more than 1" the width (W) of the Speed-Master® door supplied, DO NOT install the door. Contact Hörmann Flexon at (800) 365-3667.

3.3 Control System and Control Elements

ATTENTION

Only carry out the electrical installation if you are a qualified electrician or have been adequately instructed by a qualified electrician, and are able to meet the following requirements:

- ▶ You recognize the hazards that electricity involves.
- ▶ You are acquainted with the applicable regulations concerning electricity.
- ▶ You can use and take care of safety equipment.
- ▶ You know how to administer first aid.

Make sure that the electrical installation complies with the applicable safety requirements.

Do not apply any external voltage to the connecting terminals of the control unit. This will completely destroy the electronics.

Never pull on the connecting leads of the electrical components. This will completely destroy the electronics.

Consult the Hörmann Flexon technical support department before making any changes to any of the electrical components. Any unauthorized modifications to the control box or any electrical components of the door will void the warranty.

Install the control unit within sight of the door.

Follow any further instructions supplied which provide information on

- Making the electrical connections
- Installing additional electrical control elements

4 Initial Operation

4.1 Instructions for Initial Operation

ATTENTION

Before initial operation of the door and making it operational, check that it is in good working order and free of defects.

4.2 Setting the End-Of-Travel Positions

The end-of-travel positions of the door, are set on the control cabinet. Please pay attention to the instructions for the operator and control (see chapter 7 also).

Set the end-of-travel positions as follows:

CLOSE end-of-travel position

- The bottom profile makes full contact with the floor

OPEN end-of-travel position

- Clearance ~ 3/4" (8.2) to the seal profile lower edge

ATTENTION

If the door travels beyond the OPEN end-of-travel position, there is a risk of the door curtain slipping out of the side guides and sustaining damage.

4.3 Mounting the Warning Signs

Each Speed-Master® High-Speed Roll-Up door comes with two warning signs as shown below.

Make sure that one sign is mounted on each side of the wall on which the door is mounted.

IMPORTANT: The size (width x height) is written on a tag attached to one of the guide tracks. There is also a tag on the gearbox which shows the size.



For obvious safety reasons, both signs must be displayed as described above.

4.4 Test Run

After installing the door, test the functional safety according to the product report. Place on record in the inspection book, dated and signed, that a test run has been successfully completed. Also make note of this information on the front cover of this manual.

ATTENTION

After installing, testing and inspecting the door, hand the entire door documentation to the owner or operator of the door.

5 Operating the Door

WARNING



Door movements

Door travel may injure persons or damage objects.

- ▶ Make sure that no persons or objects are in the door's closing area during operation.
- ▶ Make sure that the door has opened completely before driving in or out! Never drive or walk through doorways unless the door has reached the OPEN end-of-travel position.
- ▶ Whenever driving in or out of the opening, always check that the door curtain has travelled up far enough to provide the necessary passage height.
- ▶ Never use the door to lift objects or persons.
- ▶ Do not reach into the guide or guide area while the door is in operation.

ATTENTION

Emergency operation devices

Too frequent use of the emergency operation devices may damage them. This will also void the warranty for the door.

- ▶ Only use the emergency operation devices in the case of a power failure or during repair work.

5.1 Instructions On Operating the Door

As the operator or owner of the door, you are responsible for ensuring that the following regulations (no claim made to completeness) are noted and observed:

ATTENTION

You are responsible for ensuring that only suitably instructed persons operate the door. A person is considered to be authorized, if he/she

- ▶ has received permission from you to use the door
- ▶ has received instruction as to how to operate the door safely.

Wait until the door has come to a complete stop before you walk or drive into the door's area of movement.

Never use the door to lift objects and/or persons.

Whenever driving in or out of the opening, always check that the door curtain has travelled sufficiently far up to provide the necessary passage height.

Only use the emergency operation devices in the event of a power failure or when carrying out repairs.

If used too frequently:

- ▶ there is a risk of damage
- ▶ the warranty is rendered null and void

Protect the door from aggressive and caustic substances, such as:

- ▶ nitrous reactions from stone or concrete
- ▶ cement
- ▶ plaster
- ▶ acids
- ▶ alkali
- ▶ road salt
- ▶ aggressively reacting coatings/paint
- ▶ aggressively reacting sealants

Do not open or close the door if it is windy (not an outside door).

The construction of the high speed door corresponds to the present state of the art design. Pressure marks are a result of the construction and are unavoidable.

Temperatures of over 120 degrees F. are to be avoided as damage can be caused to the curtain.

5.2 Emergency-OFF

Press the red emergency-OFF button in an emergency switch off situation.

5.3 Cleaning and Care

Use warm water together with a neutral, non-abrasive cleaning agent (household detergent, pH value 7). To clean the surface, use only a soft cloth. Rinse off any dirt and dust particles with clear water. Do not rub over the panes when dry, otherwise you risk scratching the surface.

5.4 Conversions

ATTENTION

Any conversion work to the door requires the express permission of the manufacturer. Only use components approved by the manufacturer. Using non-authorized components could overload the door construction which could bring about serious injury.

Carrying out any structural alterations to the door without the manufacturer's permission will render our warranty and product liability null and void.

6 Inspection and Maintenance of the Door

6.1 Inspection and Maintenance

ATTENTION

As the owner or operator of the door, you must have the system inspected and maintained by a specialist at least once a year in the case of more than 20 operations a day, every 6 months. Should you fail to have the door inspected and maintained as prescribed

- ▶ There is a risk of injury.
- ▶ There is a risk of damage.
- ▶ The warranty is rendered null and void.

The high speed door requires low-maintenance.

All bearings, including gearing, are maintenance-free for normal operating conditions and are greased for the working life.

WARNING

Unmaintained doors

There is a danger of injury and damage if the door is not regularly maintained. This will also void the warranty.

- ▶ Inspect and maintain the door regularly as described in these instructions or entrust this work to the manufacturer's service department.

DANGER

Mains voltage!

Contact with the mains voltage presents the danger of a deadly electric shock.

- ▶ Before undertaking any electrical work, disconnect the system from the mains supply and ensure that it cannot be inadvertently turned on **by following the OSHA approved lock out - tag out procedure.**

WARNING



Door movements

There is a danger of injury and damage if the door is actuated during inspection or maintenance work.

- ▶ Before undertaking any work, disconnect the system from the mains supply and ensure that it cannot be inadvertently turned on.
- ▶ If available, deactivate the emergency opening lever/handle.



WARNING



Falling parts

During dismantling, parts may fall and injure persons or damage property.

Cladding (option)

- ▶ Fix the cladding (e.g. with a forklift) before dismantling.

Shaft

- ▶ Fix the shaft (e.g. with a forklift) before dismantling the operator.

6.2 Maintenance

Depending on the door size and total number of cycles per year, we recommend:

If a total of 50,000 cycles per year is exceeded, service all functional elements every six months:

- Electric operator incl. gearbox safety device and brake.
- All the screw connections.
- Travel limit cut-off.
- Contact rail and decoder.
- Control system/impulse generator.

If the curtain is extremely dirty, cleaning is recommended using a proprietary cleaning agent.

ATTENTION

Adjustment and maintenance work may only be carried out in the de-energized state.

In general, we recommend entrusting maintenance/testing to your qualified Hörmann Flexon installer.

6.3 Troubleshooting

In general, we recommend entrusting maintenance/inspection to your qualified Hörmann Flexon installer.

Operator's driving power

The operating voltage must be **230 V / 1 ph (standard up to door size 10' x 10')** or 460 V / 3 ph / 60 Hz, otherwise there can be problems with the operator power (optional operating voltage 208 V / 3 ph / 60 Hz).

6.4 Inspection and Maintenance Plan

Only inspect and maintain this door if you are qualified to do so, and you have the suitable training, knowledge and practical experience which allows you to carry out inspections and maintenance correctly and safely.

When carrying out inspections and maintenance, observe the applicable regulations on occupational safety.

7 Control system

Locate and mount the Smart Start™ HFC1 control box with the following in mind: The control box should be located four (4) feet from the floor to the bottom of the box. Mount the control box on the motor side of the door. If the control box is mounted more than 6 1/2 feet from the ground, a remote E-Stop must be installed 48 inches from the floor. Refer to the Smart Start™ HFC1 **Electrical Diagrams and Operation Manual**, which is included with this manual, for details about installing the control box, plugging in the plug in connectors and powering the door.

The control system is manufactured individually for each door ordered. Attach the Electrical Diagrams and Operation Manual contained in the plastic folder provided to cable below control box. Keep the Operating and Maintenance Manual in a safe place for future reference.



ATTENTION

Each control box has its own identification number which must be quoted in the case of queries.

8 Dismantling

Only dismantle this door if you are qualified to do so, and you have the suitable training knowledge and practical experience which allows you to dismantle the door correctly and safely.

When dismantling the door, observe the applicable regulations on occupational safety.

1. Fully open the door.
2. Carefully roll up the door manually (emergency manual operation).
3. Tape round the door curtain several times using strong adhesive tape (e.g. packing tape) to prevent it from unrolling.
4. Drive a forklift truck with suitable pallet underneath the rolling door curtain, such that the rolling door curtain rests on the pallet.
5. Release the fastenings securing the bearing and the operator.
6. Lift the rolling door curtain together with the operator and bearing off the support brackets.



ATTENTION

The operator or the bearing or safety device can slip off the barrel journal. When letting the rolling door curtain down, take care to keep it level.

7. Dismantle the side guides and support brackets.
8. Disassemble the door into component parts and dispose of them in the proper manner.

Installation of Side Columns

1. Remove pillow block bearings from the bearing mounting brackets at the tops of the side column assemblies (fig. 1) and install them on the end shafts of the roll tube assembly.



Figure 1

2. With side column doors still bolted closed, lift the side columns into place and clamp them to the jamb (fig. 2)



Figure 2

3. Before disengaging forklift (or other lifting device) from the side columns, remove the machine screws from the face of the side columns and open the side column doors (fig. 3)



Figure 3

4. Re-install each clamp (fig. 4) for a more secure hold of the jamb



Figure 4

5. After installing clamps, forklift (or other device) can be removed.
6. Adjust positioning of the side columns so the inside edges are the same distance apart as the ordered door width (fig. 5). This information is written at the top of the side columns. Side columns should be vertical in both directions (fig. 6) and level across the tops of the bearing mounting brackets (fig. 7)



Figure 5



Figure 6



Figure 7

Shims may be required under one of the side columns in order to accomplish levels.

7. After side columns are positioned correctly and securely clamped they may be fastened to the wall.

NOTE: Choosing the correct fasteners is the responsibility of the installer as local conditions and constructions vary.

8. The top (2) mounting holes in the tops of the side columns (fig. 8) and the mounting holes in the bearing mounting brackets (fig. 9) must be through bolted. $\frac{1}{2}$ " all thread should be used with a backer plate on the opposite side of the wall (fig. 10)



Figure 8




Figure 9



Figure 10

9. The side columns should also be secured to the wall through the internal side column brackets (fig. 11) using $\frac{1}{2}$ " fasteners.



Figure 11

10. Finally the base plates at the bottom of the side columns (fig. 12) must be secured to the floor using $\frac{1}{2}$ " concrete anchors.



Figure 12

Installation of Top Draft Seal and Wire Carrier

11. Locate the top draft seal. It consists of an Aluminum extrusion and a brush. The length of the brush and extrusion is equal to your door width.
12. The draft seal is attached to the face of the wall at the edge of the door lintel (fig. 13). Position the top draft seal so that it just touches the door panel when the door panel is down.



Figure 13

13. Locate the wire carrier. It consists of an Aluminum extrusion and 3" PVC wire retaining strips. The length is equal to the door width.
14. The wire carrier is attached to the face of the wall, flush with the tops of the guide tracks (fig 14).



Figure 14

15. The ground wire and the light curtain wire must both be run through the wire carrier between the tops of the side columns. See "Electrical Diagrams and Operation Manual" for wiring of the light curtains. Connect the ground wire on the motor side (fig. 15) and on the non-drive side (fig. 16)



Figure 15



Figure 16

16. The motor must also be grounded from the connection point on the motor side (fig. 15) to the ground symbol on the motor (fig. 17)



Figure 17

Installation Of Tube Assembly

17. Tie pieces of rope around the roll tube assembly to prevent it from unraveling. Use at least 3 pieces of rope spaced evenly
18. Make sure the pillow block bearings (fig. 18) are installed on the end shafts of the roll tube at both ends before going to the next step.



Figure 18

19. The motor/gearbox must be slid on to the drive shaft of the roll tube before lifting the tube assembly into place. The drive shaft can be identified as having a key installed. Apply anti-seize lubricant (supplied) to the drive shaft before installing motor/gearbox.
20. Lift the entire roll tube assembly approximately 4-5' off the ground and check if the motor/gearbox is hanging in a vertical position before going to the next step.

21. To achieve the motor/gearbox in a vertical position, pull the red handle on the motor down so that it hangs lower than the green handle (fig. 19). Pull the manual override chain in either direction to move the motor/gearbox (fig. 20). Once the motor/gearbox is vertical lift the roll tube assembly to the top of the side columns.



Figure 19



Figure 20

22. The pillow block bearings installed on the end shafts of the roll tube must be fastened to the bearing mounting brackets with the same fasteners and in the same location as in step 1 (fig. 21)



Figure 21

23. Fasten the motor/gearbox to the torque arm angle using the fasteners provided (fig. 22)




Figure 22

24. Ensure the panel assembly is centered between the side columns. Tighten the set screws in the pillow bearings (fig. 23)



Figure 23

25. Remove the ropes from around the roll tube and cut away the plastic protective wrap. CAREFUL: DO NOT DAMAGE THE DOOR PANEL
26. Ensure the red pull handle on the motor is in the down position (fig. 19). Fully open the side-columns and lower the panel by pulling the manual override chain (fig. 20). Lower the panel approximately 1-2' into the side columns. Close the side-columns and secure with machine screws (fig. 3).
27. Complete the wiring as per the "Electrical Diagrams and Operation Manual"
28. After wiring is completed, pull the green handle down on the motor (fig. 24). The door is now operational



Figure 24

Everything you've wanted in a high performance door, and more.



German Engineered, American Made

Our promise to you.

As one of the world's leading manufacturers of doors, we're committed to providing the best quality, value, and selection. Whether, industrial or commercial, whether it's a high performance door or loading dock equipment,

we have the door or dock product you're looking for. The Hörmann Flexon product line gives you the ability to accommodate any door or dock application with the right product from one manufacturer.



Hörmann Flexon LLC, Leetsdale, PA
Headquarters and Manufacturing Plant



High Performance Doors and Dock Equipment

For assistance call 1-800-365-3667

Environmental commitment has been part of our corporate culture for decades, from our manufacturing processes to the products we make.

In everything we do, we strive to minimize energy and resource use, through efficient processes, long-lasting quality and innovative engineering.





Puertas & Portones Automáticos, S.A. de C.V.
¡Nuestra pasión es la Solución!...

» MANUAL DE INSTALACION DE PUERTA RAPIDA SPEED-MASTER MOD.SM2600L/SM4600L.



Puertas & Portones Automáticos, S.A. de C.V.
¡Nuestra pasión es la Solución!....

WhatsApp (229) 288-1552

portonesautomaticos@adsver.com.mx
portonesautomaticos@prodigy.net.mx



RESIDENCIAL



COMERCIAL



INDUSTRIAL



MEMBER

IDA
International Door Association



V12.18

(229) 927-5107, 167-8080, 167-8007, 151-7529.



www.adsver.com.mx